



Kit Contents

1x Front Plate
1x Back Plate
1x Hanging Plate
3x Stainless steel bolts
2x Screws
2x Masonry plugs

Tool required:
Phillips Head Screwdriver

ASSEMBLY

Step 1.

With the Hanging Plate in the centre, align the Front and Back Plates. Ensure the Back Plate is positioned with the decorative, painted side facing towards the front.

Step 2.

Fasten the three plates together using the three included bolts. The bolts are screwed from the back of the Back Plate through the Hanging Plate, into the Front Plate. Use a screwdriver to fully tighten the bolts.

USAGE TIPS

Evenly loop the hose over the hanger, being careful to avoid twisting the hose. To prolong the life of your hose, before storing the hose on the hanger, turn the water off at the tap. Allow excess water to be released from the hose for storage.

INSTALLATION

Timber Installation

- If attaching to timber, we recommend that at least one of the screws engages a stud.
- Using the Hose Hanger as a template, mark the anchor locations on the wall.
- Drill 2 pilot holes 3/8 inch (10mm) diameter, 2 inch (5mm) deep at the marked locations.
- Locate the Hose Hanger over the pilot holes and attach using the included screws.

Masonry installation

- Using the Hose Hanger as a template, mark the anchor locations on the wall.
- Drill 2 pilot holes 3/8 inch (10mm) diameter, 2 inch (5mm) deep at the marked locations.
- Hammer the masonry plugs into the pilot holes.
- Locate the Hose Hanger over the pilot holes and attach using the included screws and anchors.

