



This quality spray gun has metal working parts and will require periodic lubrication. Typically this will be every few months but may occur more or less frequently depending on water hardness.

Prevent Trigger Sticking

Use the supplied silicone oil every month or so. Drop silicone oil into the stainless Steel plunger under the trigger and pump handle to distribute.

Trigger Beginning to Stick But Still Working

Use the supplied silicone oil and put a few drops into the stainless Steel plunger under the trigger. Pump the handle until it is fully operational again.

Only Use Silicon Oil

Either from Hoselink or your local hardware store.

WD-40 is quickly washed away and is **NOT** recommended

Trigger Completely Seized

Take the following steps:

1. Use pliers to unscrew the brass cap at the back of the sprayer.
2. Remove the spring & stainless Steel plunger. Push the plunger from the trigger side first, then grip with pliers from the back to remove.
3. Clean any debris or build up inside the trigger well.
4. Drop silicone oil into the cavity and around the plunger.
5. Replace plunger & spring and brass cap in reverse order.
6. Pump the trigger until it is fully operational.