



Description

The Fertiliser Spray Mixer can be used to quickly and conveniently dispense commercial fertiliser or weed spray onto lawns and garden beds, by mixing it with water supplied through a hose. Both water flow and mixing rate can be adjusted to suit via the venturi system.

Please note: This product is not suitable for use with compost or worm farm liquid. The sediment in these liquids will clog the spray outlet.

Instructions

There are two types of fertiliser – pre-mixed and concentrate - that can be used with the Fertiliser Spray Mixer.

Pre-Mix

Pre-mixed fertiliser typically comes in a bottle with mixer head already built-in (see example below/to the side). Simply unscrew the top of the bottle and pour the liquid directly into the Fertiliser Spray Mixer.

Concentrate

Follow the directions on the bottle for dilution. Typically you would add a small quantity of concentrate and top up with water.

Spraying with the Fertiliser Spray Mixer

Once the Spray Bottle is ready, connect the Fertiliser Spray Mixer to the hose via the Hoselink connector and turn on the water.

Use the Flow Control Lever to adjust the water flow on or off or to the desired setting.

We recommend setting the Mixer Control Lever between half and full for optimum results. The venturi valve draws Spray Bottle contents up and mixes it with water coming through the hose. The rate at which the Spray Bottle contents are used depends on how high you set the Mixer Control Lever. For the highest mixing ratio turn it to full. For the lowest mixing ratio set it at half.

Maintenance

Always rinse the Spray Bottle and Variable Spray Mixer Head with water after use.

