



## Kit Contents

1x Metal Ground Spike  
1x Hoselink Accessory Connector

1x Impulse Sprinkler Head

## ASSEMBLY INSTRUCTIONS

**Step 1.** Screw the Hoselink Accessory Connector to the water inlet.

**Step 2.** Push the ground spike firmly into the ground.


**Step 3.** Connect to a water supply by attaching your Hoselink-fitted hose end to the Accessory Connector on the sprinkler.

**Step 4.** Set the Impulse Sprinkler Head to the desired setting.



## USING THE SPRINKLER HEAD

It is ideal for watering large garden and lawn areas.



### OPTION 1

**Adjust the radius from 30° - 360°.** Turn the 2 silver armed rings (A) at the base of the sprinkler head to set the watering parameter.

### OPTION 2

**Water in 360° radius.** Lift the silver stopper (B) to allow free rotation of the sprinkler head around in a 360° radius

### OPTION 3

**Adjust the range and arc of the water.** Lift the or depress the silver tab (C) in front of the water outlet

### OPTION 4

**Change the spread of water.** Screw the pin (D) to the side of the silver tab in or out to interrupt the water flow, thereby spreading it closer to the sprinkler