



## Kit contents

- 1x Flow Meter Device
- 1x Reducer
- 1x Click-on Tap Connector (for use if not using Hoselink hose fittings)
- Battery installed

## Assembly Instructions

Screw the device onto your tap, with or without the reducer as required to fit the tap. Attach the standard Tap Connector to the base of the device.

### WARNING

When installed at the tap, be careful not to tug hard on the hose as the device could snap.

## Legend

- A** Resets back to zero for each watering session.
- B** Resets Accumulated Water Usage back to zero.
- C** Measures water volume per watering session.
- D** Measures Accumulated Water Usage volume.



The default measurement is LIT (litres).

## Operation

### Battery save mode

The screen fades out in 30 minutes if there is no water flow or no button activation.

### Starting from zero

Press button **A** or **B** (or both **A** & **B**) to reset to zero.

When water flow commences, both **D** and **C** will count the flow volume.

To zero out the reading on **D**, press button **A**.

The reading at **C** continues to accumulate water volume until it is zeroed. To reset both **D** and **C** back to zero, press button **B**.

### Switching from Litres to Gallons

1. Press button **A** for 3 seconds and release. A dark point on the left will flash.
2. Select GAL or LIT by pressing button **B**, then press button **A** to confirm setting.
3. In this mode, the flow meter counter will revert to counting function in 30 seconds if no button is pressed.

## Troubleshooting

If the device becomes blocked, try backwashing to remove any debris.

## Set up

