

User Manual

Model: L260 | **Wide Angle Solar Wall Light with Sensor 62LED**



The Wall-mount Solar Floodlight comes with a large solar panel and 62 super bright LEDs ideal for use as a security light for added property protection, or for illuminating driveways, paths and patios.



Lighting Modes

Dim light with sensor mode (flashes once) - continuously emits a dim light (18LEDs) from dusk until dawn, with a bright light for 15-20seconds when motion is detected.

Bright Sensor Mode (Flashes 2 times) - Light remains on standby mode until motion is detected and bright light is emitted for 15-20 seconds.

Medium Light Mode (Flashes 3 times) - Light automatically comes on at dusk and off at dawn. Overnight light duration depends on amount of light exposure to the solar panel during the day.

Product Installation - OPTION 1

Adhere using Hoselink Outdoor Acrylic Double Sided Tape (SKU L100).

Product Installation - OPTION 2

Follow these steps to mount to the wall or fence using the supplied plugs and screws:

Step 1 - Find a suitable location

Solar lights need access to direct sunlight, preferably 6-8 hours per day. The motion sensor will detect movement up to 5m away.

Step 2 - Mounting the solar light

Use a 6mm drill piece for masonry installation. Gently hammer the plugs into place and then secure

the screws tightly. For timber use a 3mm drill piece without the plugs.

Step 3 - Turn on the light

To activate the light, turn on the switch on the side of the unit. Test by covering the solar panel completely to check that the light comes on. The light is now ready for use.

Note: If the light does not turn on this could be due to the battery not being charged. Leave out in direct sunlight for 6 – 8 hours and try again.

For more information visit
www.hoselink.com.au
or call **1300 900 617**