## HOSELINK \*

## COMPARISON GUIDE

. . . . . . . . . . . . . . . . .

Kit name	Fittings included	About the sprayer	Key Benefits
OUTBACK STARTER KIT	<ul> <li>Tap Connector</li> <li>Hose End Connector x2</li> <li>Accessory Connector</li> </ul>	<ul> <li>Name: Basic Spray Nozzle</li> <li>How To Use: Turn nozzle end to adjust spray from mist/fan through to jet.</li> <li>Thumbs Up</li> <li>Lightweight</li> <li>Doesn't impede water flow</li> <li>Considerations</li> <li>No stop/start trigger function</li> <li>Does not meet some council guidelines</li> </ul>	<ul> <li>A simple, lightweight sprayer</li> <li>Good for use with water tanks and caravans</li> </ul>
DAINTREE STARTER KIT	<ul> <li>Tap Connector</li> <li>Hose End Connector x2</li> <li>Accessory Connector</li> </ul>	Name: Flow Control Spray Nozzle How To Use: Adjust lever with thumb to start spraying. Turn brass nozzle at front to adjust spray from mist through to jet. Thumbs Up • Durable • No trigger to break or plunger to lubricate • Fully adjustable water flow Considerations • Doesn't feature various spray settings	<ul> <li>Ability to adjust the water flow without having to go back to the tap</li> </ul>
PREMIUM NED KELLY STARTER KIT	<ul> <li>Tap Connector</li> <li>Hose End Connector x2</li> <li>Accessory Connector with Swivel</li> </ul>	<ul> <li>Name: Premium 7-Function Spray Gun</li> <li>How To Use: Depress trigger to spray. Turn the front face to change between spray settings.</li> <li>Thumbs Up</li> <li>Versatile spray functions</li> <li>Serviceable</li> <li>Our most popular sprayer</li> <li>Considerations</li> <li>Heavier front end means it should not be dropped</li> <li>May require periodic lubrication of plunger</li> </ul>	<ul> <li>7 spray settings: shower, mist, flush, cone, centre, flat and jet</li> <li>Proven, versatile and reliable</li> <li>Swivel function makes waterin easier</li> </ul>
WATER WISE STARTER KIT	<ul> <li>Tap Connector</li> <li>Hose End Connector</li> <li>Hose Connector with Flow Control</li> <li>Accessory Connector with Swivel</li> </ul>	Name: Premium 7-Function Spray Gun How To Use: Depress trigger to spray. Turn the front face to change between spray settings. Thumbs Up • Versatile spray functions • Serviceable • Our most popular sprayer Considerations • Heavier front end means it should not be	<ul> <li>Ability to adjust water flow via lever</li> <li>Turn water off at hose end to switch watering accessories</li> <li>Swivel function makes waterin easier</li> <li>7 spray settings: shower, mist, flush, cone, centre, flat and je</li> </ul>

dropped

• May require periodic lubrication of plunger